

Dear Practitioner:

The fabrication of the dorsi flexion assist ankle joint AFO utilizes the “straight” ankle joint as a mold in the vacuum forming process. Your technical staff will notice a slight increase of space at the posterior stop during the fabrication process that is due to the cut of the saw blade and the length of the ankle joint in the extended position. If necessary the practitioner may choose to reduce the space by adding a posterior stop of weld material or use a Becker posterior stop model number: 795.

Thank you.