

1. Place the U-Flate sleeve onto the expansion platform and clamp the sleeve to the platform.



2. Attach a compressed air hose to the expansion platform air valve and inflate the U-Flate skin sleeve. After the sleeve has expanded, use a heat gun to apply heat to the sleeve. After the sleeve cools, remove the sleeve from the platform.



3. Pull the U-Flate skin sleeve over the prosthesis.



4. Use a heat gun to apply heat to the sleeve, allowing the sleeve to shrink to fit the prosthesis.

