


Size: W6 - W6.5

Length: **8.94**" | 227mm

Heel Width: 2.33" | 59.2mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W7 - W7.5 M6 - M6.5

Length: **9.34**" | 237mm

Heel Width: 2.42" | 61.3mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W8 - W8.5 M7 - M7.5

Length: 9.73" | 247mm

Heel Width: 2.51" | 63.6mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W9 - W9.5 M8 - M8.5

Length: 10.11" | 256.5mm

Heel Width: 2.60" | 65.9mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W10 - W10.5 M9 - M9.5

Length: **10.52**" | 267mm

Heel Width: 2.64" | 67mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W11 - W11.5 M10 - M10.5

Length: **10.91**" | 277mm

Heel Width: 2.72" | 69mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W12 - W12.5 M11 - M11.5

Length: **11.29**" | 286.5mm

Heel Width: 2.82" | 71.5mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: W13 - W13.5 M12 - M12.5

Length: **11.78**" | 299mm

Heel Width: 2.85" | 72.4mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: M14 - M14.5

Length: **12.51**" | 317.5mm

Heel Width: 2.95" | 74.8mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.






Size: M15 - M15.5

Length: **12.90**" | 327.5mm

Heel Width: 3.07" | 78mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.





Size: M16 - M16.5

Length: **13.41**" | 340mm

Heel Width: 3.19" | 81mm

- 1. Place heel against wall.
- 2. Measure length from wall to the tip of your big toe.
- 3. Choose the insole that fits the length of your foot. If the length of your foot is between sizes, choose a size down.

