BrainRobotics

KNEURO USER GUIDE

KNEURO APP





i08

Android

PARAMETER ADJUSTABILITY

In the Kneuro App, users can make limited adjustments to the following parameters, based on the original settings determined by their clinician.

Yielding Resistance	Provides smooth, controlled knee bending during weight-bearing activities like sitting, stair descent, and ramp navigation.
Initial Contact Resistance	Absorb impact and provide support for a smoother and more stable walking experience.
Extension Resistance	Controls how smoothly and steadily the knee straightens while standing and walking.

MODE SELECTION

Users can switch between Standard and Custom Modes in the Kneuro app, including Golf and Cycle Modes, with quick access to a designated mode via the control button.

BATTERY LIFE & STEP COUNT

Users can check the battery life of their device and view their total step count in the Kneuro app.

CONTROL BUTTON

Power ON/OFF

second hold

Manual Lock



second hold

*in full extension

Quick Access - Mode Selection



Double tap

*must be programmed in Kneuro app