

Elbows

E-200 Elbow

HOSMER

50646 Yoke Assembly

Includes:

CC.	50675	Nut
DD.	50674	Bumper
EE.	50621	Yoke

54155 Internal Assembly

Includes:

** FF.	50647	Internal Cage Assembly
GG.	50680	Bolt
HH.	50636	Locking Bar Spring
II.	50624	Base
JJ.	50679	Screw

50647 Internal Cage Assembly

Includes:

KK.	50625	Cage
LL.	50635	Locking Bar
MM.	50813	Pin
NN.	50628	Cam
OO.	50629	Spring
PP.	50626	Cam Bearing
QQ.	50627	Screw
RR.	50632	Ratchet
** SS.	50648	Lever Assembly

50648 Lever Assembly

Includes:

RR.	50630	Pawl
SS.	50705	Spring
TT.	50574	Lever
UU.	50706	Pin

